



# SILT FENCE


1. SET THE STAKES, 18" DEEP AND 6' O.C.




2. EXCAVATE A 4" X 4" TRENCH UPSLOPE ALONG THE LINE OF STAKES.





3. STAPLE 14 GAUGE WIRE FENCING TO THE STAKES. (WHERE REQUIRED)



4. ATTACH FILTER FABRIC TO WIRE FENCING.



BACKFILL AND COMPACT THE EXCAVATED SOIL



## CONSTRUCTION OF A FILTER BARRIER

SOURCE: INSTALLATION OF STRAW AND FABRIC FILTER BARRIERS OF SEDIMENT CONTROL, SHERWOOD AND WYANT

NOTE: SEE WATER MANAGEMENT AND SEDIMENT CONTROL FOR URBANIZING AREAS, USDA, SCS, FOR SPECIFICATIONS AND DESIGN CRITERIA.

SEE D-11, SEDIMENT AND EROSION CONTROL NOTES

APPROVED 8-19-93

*Kent Huston*  
CITY ENGINEER

REVISED: 8-23-93

SEDIMENT CONTROL  
SILT FENCE

CITY OF LANCASTER, OHIO  
DEPARTMENT OF ENGINEERING

STANDARD  
CONSTRUCTION DRAWING

DWG. BY: C.S.W.  
CHK'D BY: RM

FILE NUMBER  
D-6