



## SILT FENCE



1. EXCAVATE A 6"x6" TRENCH ALONG THE PROPOSED FENCE LINE.



2. PLACE FABRIC AND SUPPORT STAKES AND EXTEND FABRIC INTO THE TRENCH



3. BACKFILL AND COMPACT THE EXCAVATED SOIL



### CONSTRUCTION OF A FILTER BARRIER

- NOTE: 1. SEE ODOT CONSTRUCTION ADMINISTRATION MANUAL OF PROCEDURES ITEM No. SS 832 TEMPORARY SEDIMENT AND EROSION CONTROLS FOR SPECIFICATIONS AND DESIGN CRITERIA.
2. FURNISH 30" WIDE GEOTEXTILE FABRIC WITH SOUND WOOD SUPPORTS WITH MAXIMUM O.C. SPACING OF 10'. USE GEOTEXTILE FABRIC CONFORMING TO ITEM No. 712.09, TYPE C.

SEE D-11, SEDIMENT AND EROSION CONTROL NOTES

APPROVED 7-13-20  
  
 CITY ENGINEER

SEDIMENT CONTROL  
 SILT FENCE  
 (ODOT DM-4.4)

CITY OF LANCASTER, OHIO  
 DEPARTMENT OF ENGINEERING

STANDARD  
 CONSTRUCTION DRAWING

DWG. BY: ADH  
 CHK'D BY: MN

FILE NUMBER  
**D-5**

REVISED: 13 JUL 20